

## 1. INFORMATION DISPLAY

### 1. FUEL CONSUMPTION

#### FUEL CONSUMPTION (VEHICLES WITH HYBRID SYSTEM)

Fuel consumption information, such as that shown below, can be displayed on the screen. For details see Section 1-1 of "Owner's Manual".


- Energy monitor
- Trip information
- Past record

#### FUEL CONSUMPTION (VEHICLES WITH GASOLINE ENGINE)

#### PAST RECORD

Fuel consumption information from recent resets can be displayed.


- 1 Press the "MENU" button on the Remote Touch.




- 2 Select "Info/Apps".



- 3 Select "Fuel Consumption".



- 4 This screen will be displayed.




- If the "Past Record" screen does not appear, select "Past Record" on the "Trip Information" screen.
- The average fuel consumption history is divided by color into past averages and the average fuel consumption since the last update. Use the displayed average fuel consumption as a reference.
- Update the average fuel consumption by selecting "Update" to measure the current fuel consumption again.
- Past record data can be deleted by selecting "Clear".

TRIP INFORMATION

The average fuel consumption of the last 15 minutes can be displayed in one-minute blocks.

- 1 Press the “MENU” button on the Remote Touch, then select “Info/Apps”.
- 2 Select “Fuel Consumption” on the “Information” screen.
- 3 This screen will be displayed.



No.	Function
1	Average speed
2	Elapsed time
3	Cruising range
4	Previous fuel consumption per minute
5	Current fuel consumption per minute

- If the “Trip Information” screen does not appear, select “Trip Information” on the “Past Record” screen.
- Consumption data can be deleted by selecting “Clear”.
- Average fuel consumption for the past 15 minutes is divided by color into past averages and averages attained since the “ENGINE START STOP” switch was last turned to IGNITION ON mode. Use the displayed average fuel consumption as a reference.

## 1. INFORMATION DISPLAY

## 2. MAP DATABASE VERSION AND COVERAGE AREA

### MAP INFORMATION

Coverage areas and legal information can be displayed and map data can be updated.


- 1 Press the "MENU" button on the Remote Touch.



- 2 Select "Info/Apps".




- 3 Select "Map Data".



- The "Map Information" screen will be displayed.

### INFORMATION


- Map data updates are available for a fee. Contact your Lexus dealer for further information.
- The "Map Information" screen displays **1** "Map Version" and **2** "Map Update ID". This data is needed to perform a map data update.



### LEGAL INFORMATION

Legal information related to the map data can be displayed.

- 1 Press the "MENU" button on the Remote Touch, then select "Info/Apps".
- 2 Select "Map Data" on the "Information" screen.
- 3 Select "Legal Info.".




- The "Legal Information" screen will be displayed.

MAP COVERAGE

Map data coverage areas can be displayed.

- 1 Press the “MENU” button on the Remote Touch, then select “Info/Apps”.
- 2 Select “Map Data” on the “Information” screen.
- 3 Select “Map Coverage”.



- The “Map Data Coverage” screen will be displayed.

CERTIFICATION

► For vehicles sold in Canada

- This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.
- Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
- This device complies with RSS-310 of Industry Canada. Operation is subject to the condition that this device does not cause harmful interference.
- Cet appareil est conforme au CNR-310 d'Industrie Canada. Son exploitation est autorisée sous réserve que l'appareil ne cause pas de brouillage préjudiciable.